

HPPP2GSC Weatherproof twin socket with independently wire-able circuit feature, can have the circuits indentified using IPA studs™ shown below



Using a small screw driver, remove the IPA stud™ filler cap.



Trim the shaft of the circuit identification IPA stud™ down and press in place.



Separate circuits for the independently wired sockets can be indentified as shown