

FLPP1GCBA
FLPP2GCBA
FLPPSW2GCBA
FLPP2USBAUCBA
FLSWPV1GCBA
FLSWPV2GCBA
FLSWPV3GCBA
FLSWPV4GCBA
FLSWPV5GCBA
FLSWPV6GCBA

See current catalogue for further detail

Cleaning Guide:

Spraying cleaning products on to electrical products is not recommended.


It is important to ensure that switches are turned off before cleaning.

Do not use any cleaning sprays - only wipe down with damp cloth or rub with dry cloth. (Do not use an abrasive cloth as it may scratch the plastic).

Do not use harsh chemical cleaners as these can break down the plastic and cause it to crack.

Brushed Aluminium Covers

- Brushed Aluminium covers provide a great protective upgrade to switches and power points and do not fingerprint as much as other materials while providing a similar look.
- The brushed finish is complemented with the décor of other brushed stainless appliances or looks stylish on other backgrounds.



Example of cover plate
FLPPSW1GCBA



Example of cover plate with
FLPPSW1GCBA with FLPPSWV1G



Example of cover plate with
FLPPSW1GCBA with FLPPSWV1GBK

Catalogue Number	Description
FLPP1GCBA	Power Point Switched 1 Gang Cover Only Brushed Aluminium
FLPP2GCBA	Power Point Switched 2 Gang Cover Only Brushed Aluminium
FLPP2USBAUCBA	Power Point 2 Gang with Dual USB Cover Only Brushed Aluminium
FLPPSW2GCBA	Power Point Switched 2 Gang with Removable Extra Switch Cover Only Brushed Aluminium
FLSWPV1GCBA	Switch Plate Vertical 1 Gang Cover Only Brushed Aluminium
FLSWPV2GCBA	Switch Plate Vertical 2 Gang Cover Only Brushed Aluminium
FLSWPV3GCBA	Switch Plate Vertical 3 Gang Cover Only Brushed Aluminium
FLSWPV4GCBA	Switch Plate Vertical 4 Gang Cover Only Brushed Aluminium
FLSWPV5GCBA	Switch Plate Vertical 5 Gang Cover Only Brushed Aluminium
FLSWPV6GCBA	Switch Plate Vertical 6 Gang Cover Only Brushed Aluminium



June 2026