


SENSWPV1G
SENSWPV1GBK
SENSWPV2G
SENSWPV2GBK
SENSWPV3G
SENSWPV3GBK
SENSWPV4G
SENSWPV4GBK



Images above show Senoa Simple plates using rocker mechs



Images above show Senoa Simple plates using push button mechs


Cleaning Guide:

Spraying cleaning products directly on to electrical switches or power points (sockets) is not recommended. It is important to ensure that switches are turned off before cleaning.

Do not use any cleaning sprays - only wipe down with damp cloth or rub with dry cloth. (Do not use an abrasive cloth as it may scratch the plastic). Do not use harsh chemical cleaners as these can break down the plastic and cause it to crack. Do not wash the cover plates in water over 60°C.

Senoa Simple Switch Plates

- Switch plates only (less mechs)
- Plates can be fitted with Trader Meerkat MESWC 'cats eye' mechs, including TV and Data; and Clipsal 30 Style* mechs and accessories (see below to find product codes of Trader compatible mechs).
- Fits standard Australian wall boxes and mounting accessories that use 84mm mounting centres
- Uses integral 'Cat Flap' screw covers for mounting screws
- Covers plates are made from UV resistant polycarbonate
- Standard colour is White. Also available in Black.
When ordering BLACK product add "BK" at end of catalogue number, ie SENSWPV1GBK
- Typical example of size in diagram:



Can be used with traditional rocker switch mechanisms or push button mechanisms

Catalogue Number	Description
SENSWPV1G	Switch Plate 1 Gang (Less Mech) White
SENSWPV2G	Switch Plate 2 Gang (Less Mech) White
SENSWPV3G	Switch Plate 3 Gang (Less Mech) White
SENSWPV4G	Switch Plate 4 Gang (Less Mech) White

When ordering BLACK product add "BK" at end of catalogue number, ie **SENSWPV4GBK**

MEERKAT

Meerkat Switch Mechanisms are recommended for rocker switch options in all switch plates

Product codes include: MESWC, MESWC20, MESWC32, MESWCDP20, and more.

See Meerkat Tech Data Sheets or visit gsme.com.au to view full product range and/or download information.

Meerkat Push Buttons recommended for use in switch plates:

MEPB [Push Button, Electronic On/Off Switch, 3-wire]

MEPBMW [Push Button, Multi-Way Remote Dimming and On/Off]

Dimpala Push Button Digital Dimmer recommended for use in switch plates:

DIMPBD [Dimpala Push Button Digital Dimmer, Trailing Edge]

GSM Electrical (Australia) Pty Ltd

5-9 Rundle Street, Kent Town SA 5067

P: 1300 301 838 F: 1300 301 778 E: service@gsme.com.au

www.gsme.com.au