

MMW958V



Care and Cleaning

Warning: Be sure to unplug the appliance from the power supply.

- Clean the cavity of the oven after using with a slightly damp cloth.
- Clean the accessories in the usual way in soapy water.
- The door frame and seal and neighbouring parts must be cleaned carefully with a damp cloth when they are dirty.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

Please follow the Care & Cleaning Instructions in accordance to the Use & Care guide supplied.

Mistral 20 Litre Digital Microwave Oven

Features:

- Digital control with LED display
- 99:99 minutes timer setting
- 6 Auto cooking menus
- 11 Microwave power levels
- Defrost setting
- Child safety Lock
- 650-700W Microwave power
- 12 Month Warranty

Product Dimensions:

440 (L) x 328 (W) x 259 (H) mm

Catalogue Number	Description
MMW958V	Mistral Microwave Oven, 20L Digital Microwave Oven, 700 Watts, 6 Auto Cooking Menus + 11 Microwave Power Levels

Distributed by:

GSM Electrical (Australia) Pty Ltd

Level 2, 142-144 Fullarton Road, Rose Park SA 5067

P: 1300 301 838 F: 1300 301 778 E: service@gsme.com.au

www.gsme.com.au